

(3) A) Insert the RS3000 harness' 2P female (terminals)connector into the Glass Breakage Sensor's 2P male (terminals) connector, then secure the connectors to the RS3000 harness using one medium wire tie as shown. Fig 46

B) Reinstall the gear shift cover. Fig 46

