


# SYSTEM LAYOUT AND CONNECTIONS



A	RS3000 ECU Connectors (10P, 10P, 4P)	F	⊕ Output Wire For Piezo "Chirper" (RED)
B	Glass Breakage Sensor Controller Connector (6P Clear)	G	Glass Breakage Sensor (Mic.) Connector (2P Clear)
C	Theft Deterrent/Door Lock ECU Connectors (25P Orange Female/25P White Male)	H	Antenna Wire (GRAY)
D	Theft Deterrent/Door Lock ECU Connectors (9P Orange)	O	Piezo "Chirper" ⊕ Wire (RED)
E	Door Courtesy Wire (RED/WHITE)	P	Piezo "Chirper" ⊖ Wire (BLACK)